1/3




FIG. 2 ENTER CELL INFORMATION INTO 18-PLACE AND ROUTE TOOL GENERATE CONFIGURATION FILE 20~ FOR SETTING DATAPATH CELLS IN PLACE AND ROUTE TOOL ASSIGN FIXED STATUS TO 22-DATAPATH LAYOUT IN PLACE AND ROUTE TOOL PLACE REMAINDER OF STANDARD CELLS IN PLACE 24-AND ROUTE TOOL ENTER CONSTRAINTS FOR LAYOUT OF REMAINDER OF CELLS 26-GENERATE FINAL 28 LAYOUT INFORMATION

